

WallSpring™ Decorative Accents Installation Instructions

Installation Guidelines

WallSpring™ Decorative Accents should be installed on the vertical surface using a flexible material like marine grade silicone.

Plumbing should be installed through the wall of the pool or fountain in the exact location for the installation of the Accent. A valve should be installed on each plumbing line to the Accents. If multiple Accents are installed, separate valves need to be installed in positions that allow individual adjustment.

Installation of all Accents except the Sconces

Place Accent on the wall over the pipe. Measure and align the Accent and mark the exact location. Measure the pipe length from the wall to the socket and make the appropriate cut. Guidelines for each of the units is shown on the reverse along with dimensions and weights. Apply the silicone in a continuous bead around the back of the Accent. Apply silicone to the pipe and in the hole of the Accent. Make sure to use a smooth tool to remove the excess in and around the water exit hole to assure proper water flow through the mouth. The adhesive should hold the Accent in place. In the event the unit does not stay secure, apply tape or similar means to the unit. Once the adhesive is dry, the Accent will be secure.

Sconce Installation

Installing a Sconce requires a slightly different installation technique. First, align the Sconce and mark where the pipe needs to penetrate the back. Next, drill a pipe installation hole using the 1" drill bit. (NOTE: It is preferred that the hole is as low on the back as possible to help level the water flow. In the event this is not possible, allow enough room in the unit and the cut the pipe to allow for a ¾" 90 degree elbow to be installed. Apply the silicone in a continuous bead around the back of the Sconce and around the pipe hole. Install the Sconce, align and then install additional adhesive around the pipe hole. Make sure to wipe off all excess adhesive. Allow the adhesive to dry and the unit is ready to be started.

Technical support

Sanford, North Carolina (8 A.M. to 5 P.M. - ET)

Moorpark, California (8 A.M. to 5 P.M. - PT)

Phone: (800) 831-7133

Fax: (800) 284-4151

Web sites: www.pentairpool.com - www.staritepool.com

© 2008 Pentair Water Pool and Spa, Inc. All rights reserved.
This document is subject to change without notice.
1620 Hawkins Ave., Sanford, NC 27330 • (919) 566-8000
10951 West Los Angeles Ave., Moorpark, CA 93021 • (805) 553-5000

Trademarks and Disclaimers:

WallSpring™ and Pentair Water Pool and Spa® are trademarks and/or registered trademarks of Pentair Water Pool and Spa, Inc. and/or its affiliated companies in the United States and/or other countries. Unless noted, names and brands of others that may be used in this document are not used to indicate an affiliation or endorsement between the proprietors of these names and brands and Pentair Water Pool and Spa, Inc. Those names and brands may be the trademarks or registered trademarks of those parties or others. Printed in U.S.A.

590052(Rev A) 3/10/2008



Installation Specifications and Dimensions

(All WallSpring™ require a 3/4" supply pipe)

Series #	Description	Weight (lbs.)	Dimensions (W x L x D)	Pipe Length	Pipe Location From Center
582000	Neptune	7.00	10½" x 11¼" x 3"	1 ¾"	Down 2 ½"
582010	Expression	2.00	4½" x 5½" x 2"	1"	Down 1 ¼"
582030	Rosette-Biscayne	4.00	7¼" x 7¼" x 1½"	¾"	Center
582040	Rosette-Aegean	3.00	7¼" x 7¾" x 1¼"	¾"	Down ¾"
582050	Lion, Baroque	5.00	7½" x 9" x 4 1/8"	2"	Down 1 ¼"
582060	Lion, Baroque	7.00	10½" x 12" x 4 1/8"	2"	Down 1"
582070	Lion, Baroque	15.00	13½" x 17½" x 5 1/8"	2 ¾"	Down 3 ¼"
582080	Lion, Roman	5.00	8½" x 11" x 4¼"	1 ½"	Down 1 ¾"
582090	Lion, Victorian	3.00	6½" x 6½" x 4½"	1 ¾"	Down 1"
582100	Lion-Renaissance	3.00	8" x 8" x 2½"	1 ¼"	Down 1 ½"
582110	Lion-Monarch	7.00	8½" x 11¾" x 5¼"	1 ½"	Center
582120	Lion-Sun	5.00	10" x 10" x 2"	1 ½"	Down 1 ½"
582130	Lion-Regal	7.00	8¾" x 12" x 4¼"	1 ½"	Down 2"
582150	Rosette-circle leaves	3.00	7" x 7" x 1"	¾"	Center
582160	Rosette-fluted	3.00	8½" x 8½" x 1½"	1"	Center
582170	Rosette-4 point	3.00	6¾" x 6¾" x 1"	¾"	Center
582180	Rosette-scalloped	3.00	8" x 8" x 1½"	7/8"	Center
582190	Rosette-sunflower	3.00	8" x 6 ½" x 1¼"	7/8"	Center
582200	Rosette-sunflower	8.00	14" x 11½" x 2"	1 ¾"	Center
582210	Rosette-Star	2.00	4½" x 4½" x 1"	½"	Center
582220	Rosette-Star	3.00	6¾" x 6¾" x 1"	¾"	Center
582230	Rosette-Oak Leaf	3.00	4¾" x 4¾" x 1¼"	¾"	Center
582240	Rosette-Art Deco	3.00	5¾" x 5¾" x 2¼"	1"	Center
582250	Rosette-Chanterelle	3.00	6¼" x 8¾" x 1"	¾"	Center
582260	Rosette-Round	5.00	8½" x 8½" x 1"	¾"	Center
582270	Rosette-Sq. Fern	5.00	10¾" x 10¾" x 1¼"	½"	Center
582280	Rosette-Sq. Dahlia	5.00	10¾" x 10¾" x 1¼"	¾"	Center
582290	Sconce-Fleur de Coeur	4.00	9" x 7" x 4"	¾"	Up 1"
582300	Sconce-Fleur de Lis	11.00	22" x 12" x 8"	¾"	Down 2"
582310	Sconce-Versailles	11.00	16" x 12" x 7"	¾"	Up 1 ½"
582320	Sconce-Bastion	5.00	12" x 6¼" x 5½"	¾"	Down ½"
582330	Sconce-Gothic	5.00	12" x 6¼" x 5½"	¾"	Down ½"
582340	Sconce-Rip Van	5.00	7½" x 7 ¼" x 3"	¾"	Down 1"
582350	Sconce-Sheer Lion	5.00	7 1/8" x 9 1/8" x 3"	¾"	Down 1"
582360	Sconce-Tuscany	7.00	13 3/8" x 6 7/8" x 3¾"	¾"	Center
582370	Sconce-Corinthian	5.00	9" x 8½" x 43/4"	¾"	Center
582380	Sconce-Polynesia	4.00	7 ¼" x 7" x 4½"	¾"	Up ½"
582390	Sconce-Sonrisa	7.00	14½" x 7¼" x 6"	¾"	Center
582400	Shell-Conch	3.00	5½" x 7" x 3"	½"	Right 1"
582410	Shell-Nutilus	3.00	3" x 6" x 3½"	½"	Down 1 ¼"
582420	Shell-Fossil Nutilus	3.00	8¼" x 7" x 2"	¾"	Down 1"
582430	Shell-Hand Hold	3.00	7¼" x 6" x 2"	N/A	N/A
582440	Handhold-St. Lucie	3.00	6" x 6" x 2"	N/A	N/A
582450	Handhold-St Augustine	3 lbs	6" x 6" 2½"	N/A	N/A
582460	Handhold-Lion	2.00	6" x 6" x 2½"	N/A	N/A
582470	Rosette-Basque	2.50	7¼" x 7¼" x 1"	¾"	Center
582480	Carp	4.00	9¼" x 6¾" x 3½"	1"	Down ½"